

BEFORE YOU BEGIN



WARNING: Risk of personal injury or product damage. Handle with care.

Vitreous China can break or chip if the bolts and nuts are over-tightened, or if the product is handled carelessly.

- Observe all local plumbing and building codes.
- Carefully inspect the new toilet for any damage.
- If the Inwall tank is not installed, refer to the manufacturer's instructions before installation.

ORDERING INFORMATION

ESCALE® Wall-hung Toilet.....K-16817IN*
 Includes ESCALE® Wall-hung Toilet Bowl.....K-19045IN*
 Includes ESCALE® Quiet-close Toilet Seat.....K-4417T*/ K-4417IN*

* Available in "-0 (White)", "-96 (Biscuit)" & "-00 (JD White)"

RECOMMENDED TANKS

Description	Inwall Tank	Cover/ Face Plate
Hydro Tower 310 In-wall tank	K-4178IN-2-NA	K-4177IN-2-CP/ K-8857IN-2-CP

ROUGHING-IN

K-19045IN

P-Trap

RECOMMENDED TOOLS AND MATERIALS

- All dimensions in mm. Fixture dimensions are nominal and conform to tolerances as per ASME Standard A112. 19.2M.
- Product illustrations shown are representative only; actual products may vary.
- Kohler reserves the right to make changes in product characteristics, packaging or availability at any time without notice.

CAUTION : Do not use lime/cement to install the toilet. The expansion of lime/cement due to rise in temperature may cause the toilet to crack or be damaged. Kohler is not responsible for any damage caused by installation with the use of lime/cement.

INSTALLATION GUIDELINE

<p>1 Cut bolts if needed. File bolt ends.</p>	<p>2 Mount the sleeve on the bolts and remove inlet and outlet plugs.</p>	<p>3 If connector is not already installed, apply teflon tape on the connector & install.</p>	<p>4 Slide on the gaskets as shown.</p>
<p>5 Install the accessory kit into the installation hole of the toilet.</p>	<p>6 Slide the inlet pipe into the wall openings. Test fit the toilet.</p>	<p>7 Note the distance between the wall and the toilet at the location shown. Measure excess length "A" for the inlet pipe.</p>	<p>8 Cut and file the inlet pipe to the proper length by removing excess length "A".</p>
<p>9 Slide the outlet pipe into the wall openings. Test fit the toilet.</p>	<p>10 Note the distance between the wall and the toilet at the location shown. Measure excess length "B" for the outlet pipe.</p>	<p>11 Cut and file the outlet pipe to the proper length by removing excess length "B".</p>	<p>12 Add silicon sealant in the gasket grooves.</p>
<p>13 Mount the toilet on the wall.</p>	<p>14 Level the toilet and tighten accessories using allen key. Close the installation holes using the caps.</p>	<p>15 Flush the toilet. Check for leaks. Seal connections if required.</p>	<p>16 Seal around the edges. Do not use cement.</p>

Recommended Installation Parts

<p>Inlet Connection*</p>	
<p>Outlet Connection*</p>	

Wall Installation Kit**
E5534-CP

Note: Dimension A and B (as shown in picture 7 to 11 above) to be adjusted as per specific site requirements.

Toll Free 1800 103 2244

kohler.co.in

© 2006 Kohler Co.